


GLOBAL PROCUREMENT AND MARKETING LIMITED

CLARA DEEP BOOKCASE

Assembly instruction- Please keep for future reference

BKSCLA 2 DO

BKSCLA 2 DW



Dimensions	No. People	Assembly Time	OW#
Width: 78cm Depth: 29cm Height: 180cm		40 mins (approx)	0000 / 0000 0000 / 0000

thank you

For purchasing this
GPM Limited
product

Important

- PLEASE READ THESE INSTRUCTION FULLY BEFORE STARTING ASSEMBLY.
- PLEASE DO NOT THROW THE PACKAGING AWAY UNTIL YOU ARE SATISFIED WITH PURCHASE, GOODS NEED TO BE RETURNED IN ORIGINAL PACKAGING.

If you need help or have damaged or missing parts, please email aftersales@gpmfurniture.co.uk

Safety and Care Advice

Important-Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2,3 and 4.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft, level surface to avoid damaging the unit or your floor.
- We do not recommend the use of power drill/drivers for inserting screw, as this could damage the unit. only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.




Care and Maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

If you are unhappy with the product and wish to return it, please following the retailer's returns procedure.

Components - Panels



Components - Panels

If you have damaged or missing components,
email: aftersales@gpmfurniture.co.uk

Please check that you have all the components listed below before constructing your item.

[illegible]

Important-Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please email aftersales@gpmfurniture.co.uk


Components - Fixings

If you have damaged or missing components,
email: aftersales@gpmfurniture.co.uk



Please check that you have all the components listed below before constructing your item.

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

HARDWARE

(A)  JCBC #5 x 40mm x14	(B)  Nail x52	(C)  Bolt Nut Mini Fix Set x4 Sets	(D)  Leg Pin x4	(E)  Shelf Support x16	(F)  Allen Key x1
--	--	---	--	---	--


ANTI - TIPPING KITS

(G)  Screw #4 x 32mm x4	(H)  Screw #3.5 x 20mm x4	(I)  Wall Plug x4	(J)  Wall Bracket x4	(K)  Cable Tie Strap x2
--	--	---	---	---

Tools Required (Not Provided)



Ruler - Use this to measure your screws (mm)



Important-Please read these instructions fully before starting assembly


If you need help or have damaged or missing parts, please email aftersales@gpmfurniture.co.uk

Assembly Instructions

If you have damaged or missing components,
email: aftersales@gpmfurniture.co.uk


Step 1

Insert Shelf Support **(E)** to the Panel
(1), (3), (5) & (7) pre-drilled shelf holes
as shown.



Step 2


Insert Mini Fix Nut **(C)** to the pre-drilled
holes in Panel (5) & Panel (7) as shown.



Step 3


Attach Panel (1), (2), (3) & (4)
with JCBC Bolt (A) using
Allen key (F) to tighten.

If you have damaged or missing components,
email: aftersales@gpmfurniture.co.uk




Step 4

Attach Panel (5), (6), (7) & (8)
with JCBC Bolt (A) using
Allen key (F) to tighten.




Step 5




Attach by connecting Panel Box (1), (2),
(3) & (4) to joint Panel Box (5), (6), (7) &
(8) and secure with (C) Bolt
and Nut. Tighten (C) Nut as shown
with a Philip head Screw driver.

Step 6

If you have damaged or missing components,
email: aftersales@gpmfurniture.co.uk



Step 7



Install the Anti-Tipping kit as shown.

ANTI-TIPPING

