
GLOBAL PROCUREMENT AND MARKETING LIMITED

DINNER TABLE

Assembly Instructions – Please keep for future reference	DINRAD140	



Dimensions	No. people	Assembly Time	SKU #
Width: 140/90 cm Depth: 80/40 cm Height: 75/45 cm		40 mins (approx.)	DINRAD140

thank you

For purchasing this **GPM Limited** product

Important

- PLEASE READ THESE INSTRUCTIONS FULLY BEFORE STARTING ASSEMBLY
- PLEASE DO NOT THROW THE PACKAGING AWAY UNTIL YOU ARE SATISFIED WITH PURCHASE, GOODS NEED TO BE RETURNED IN ORIGINAL PACKAGING.

If you need help or have damaged or missing parts, please email support@home-source.co.uk

⚠ Safety and Care Advice

Important

- PLEASE READ THESE INSTRUCTIONS FULLY BEFORE STARTING ASSEMBLY
- PLEASE DO NOT THROW THE PACKAGING AWAY UNTIL YOU ARE SATISFIED WITH PURCHASE, GOODS NEED TO BE RETURNED IN ORIGINAL PACKAGING.

- Check you have all the components and tools listed on pages 4 and 5.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft, level surface to avoid damaging the unit or your floor.
- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.

Care and Maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


If kept outside please ensure in the winter months that the product is correctly covered or put away into a dry environment to prevent corrosion, weathering or damage.

If your product is not designed to be outside, we recommend that it is always kept indoors in a dry environment.

If you are unhappy with the product and wish to return it, please follow the retailer's returns procedure.

Exploded View







If you have damaged or missing components, email: support@home-source.co.uk



Components - Panels

If you have damaged or missing components, email: support@home-source.co.uk

Please check that you have all the components listed below before constructing your item.

Part No	Description	Qty	Size (mm)	Thickness (mm)
1		2PCS	400*900	40
2		4PCS	20*40	0.8
3		4PCS	Φ22	0.8
4		1PC	800*1400	40
5		2PCS	25*50	0.8
6		2PCS	Φ25	0.8

Important – Please read these instructions fully before starting assembly


If you need help or have damaged or missing parts, please email **aftersales@gpmfurniture.co.uk**

Components - Fixings


If you have damaged or missing components, email: support@home-source.co.uk

Please check that you have all the components listed below before constructing your item.

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

(A)	 12PCS	**(B)**	 36PCS	**(C)**	 4PCS	**(D)**	 4PCS
(E)	 12PCS	**(F)**	 24PCS	**(G)**	 24PCS	**(H)**	 1PC

Ruler – Use this to measure your screws (mm)




Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please email **aftersales@gpmfurniture.co.uk**


Assembly Instructions

If you have damaged or missing components, email: support@home-source.co.uk

Step 1




Step 2



Assembly Instructions

If you have damaged or missing components, email: support@home-source.co.uk

Step 3



Step 4

